


SUPERLIFT

LOAD CAPACITY:

20 KG

(WITH POWER VARIATOR)



Aprire gli sportellini e fissare SUPERLIFT alla fiancata.

Open the small plastic caps that hide the screw holes and fasten SUPERLIFT to the side of wardrobe.

Die Türen öffnen und SUPERLIFT an der Seite befestigen.

Ouvrir les portes et fixer SUPERLIFT sur le côté.

Abrir las puertas y fijar SUPERLIFT en la parte lateral.

Svitare e raggiungere la posizione centrale dell'armadio.

Unscrew until the bar of the SUPERLIFT gets to a central position on the side of the wardrobe.

Losschrauben und die Schrankmitte erreichen.

Dévisser et atteindre la position centrale de l'armoire.

Destornillar y alcanzar la posición central del armario.

Fissare il tubo portagruce e regolare la potenza desiderata spostando la levetta posta sul retro.

Attach the hanger rod and regulate the power by using the small lever that you find in the back of the gear.

Die Kleiderbügelstange befestigen und durch verschiebendes Hebel an der Rückseite die Gewünschte stärke einstellen.

Fixer la tube portécintres et régler la puissance voulue en déplaçant la manette placée à l'arrière.

Sujetar la barra porta perchas y regular la potencia deseada desplazando la palanca situada en la parte posterior.

WALLLIFT

LOAD CAPACITY:

10 KG

